

PREPARE PRESERVE PROTECT

Roxil®

WOOD PROTECTION CREAM



Application

GUIDELINES

Application Guidelines

What You Will Need



ROXIL® WOOD PROTECTION CREAM



STIFF NATURAL BRISTLE BRUSH



SANDPAPER



PAINT BRUSHES AND/OR ROLLER

Preparation

The wood surface must be clean and dry before treatment can begin. It is recommended to use a cleaner such as Roxil® 100 Wood & Patio Cleaner to cleanse new or weathered wood surfaces before applying **Roxil® Wood Protection Cream**. This is important for new, planed wood furniture and structures such as tables, benches and decking where mould growth is common. After 24 hours, rinse Roxil® 100 Wood & Patio Cleaner off with fresh, clean water and allow to dry before applying **Roxil® Cream**. All prior coatings, or heavy grime, should be completely removed. If necessary, grey or deteriorated wood should be treated with Roxil® Wood Scrub Gel, after cleaning with Roxil® 100 Wood & Patio Cleaner, then sanded down to provide a smooth, sound surface. Only apply **Roxil® Cream** in temperatures between 5 – 30°C and not when heavy rain is forecast.

For increased protection against mould, rot and staining the surface can be primed using Roxil® Wood Preserver. Apply in accordance with application guidelines and allow the wood to dry for at least 24 hours, before applying **Roxil® Cream**.



ROXIL® 100 WOOD & PATIO CLEANER



ROXIL® WOOD SCRUB GEL



ROXIL® WOOD PRESERVER

Test Area

Roxil® Cream has been formulated as a colourless protection for use with absorbent wood such as softwood timber and weathered hardwoods. It is recommended to try a small test area before full application to determine compatibility.

Staining



If staining is required, Roxil® PC Coloured Wood Preservers are a preventative treatment against wood rotting and wood staining fungi, for use on hard and soft wood and available in a range of fade-free colours. It is recommended to apply the stain first and allow the fence to fully dry before applying **Roxil® Cream**.



ROXIL® COLOURED WOOD PRESERVERS

Coverage

Coverage rate: 4 – 5 m² per litre*

Pack size	Area treated*
1 litre	4 – 5 m ²
3 litres	12 – 15 m ²

* The coverage rate will vary depending upon the roughness and absorbency of the surface, use as a guide only.

Application



1 Before application, brush the surface to remove any loose material. Some light sanding may be necessary to remove any rough areas or edges – depending on the desired finish.



2 For best results, the wood surface should be cleansed before the application of **Roxil® Cream**. **Roxil® 100 Wood & Patio Cleaner** is recommended. Allow the wood to dry fully before applying **Roxil® Cream**.



Roxil® Cream can be applied by large brush. A smaller brush can be used for applications around details such as shed windows. Any splashes onto glass, plants or paving should be cleaned away with warm soapy water.



4 Larger areas can be covered more quickly using roller application. Clean equipment with white spirit.



5 **Roxil® Cream** appears white immediately after treatment – making it easy to identify untreated areas.



6 30 – 60 minutes after application, **Roxil® Cream** starts to penetrate into the wood and the whiteness will fade.



7 After 24 – 48 hours the wood will have returned to its original appearance and will be resistant to the harmful effects of water ingress.



8 **Roxil® Cream** will penetrate absorbent wood such as softwood timber and weathered hardwoods. The silicone waterproofs and protects the wood from the undesirable effects of moisture reducing colour loss and the tendency for cracking.



The service life of **Roxil® Cream** can be enhanced by regular maintenance using **Roxil® 100 Wood & Patio Cleaner**.



Roxil®

WOOD PROTECTION CREAM

- Waterproofs absorbent wood such as softwood timber
- Retains natural appearance
- Reduces mould and algae growth
- Reduces water uptake for improved resistance to warping
- Lasting protection for softwoods and weathered hardwoods*
- Single-coat application
- Protects wooden cladding



Compatible Products:

Roxil® 100/200 Wood & Patio Cleaners, Roxil® Wood Scrub Gel, Roxil® Wood Preserver, Roxil® Coloured Wood Preservers

Safeguard Europe Ltd
Redkirk Close,
Horsham, West Sussex,
United Kingdom. RH13 5QL

T 01403 210204 F 01403 217529

E info@safeguardeurope.com

www.safeguardeurope.com

www.roxil.com

* Based on accelerated QUV aging and good maintenance. Regular maintenance of timber will improve lifetime of product.