

NOPE!® Disinfectant Ready-For-Use

Product Description

NOPE!® Disinfectant Ready-For-Use is a broad spectrum hard surface disinfectant for use against viruses and bacteria. It is suitable for use in healthcare, hospital and other institutional areas as well as catering, hotels, restaurants and domestic settings.

The disinfectant is effective on most hard surfaces, and can be used in areas such as kitchens, bathrooms, work surfaces, tables, walls, floors and regular contact surfaces such as door handles and cupboards doors.

Benefits

- Kills Bacteria^[1]
- Kills Viruses^[2]

Properties

Appearance	Clear liquid
Recipe Type	Low-viscosity; water based
Density	1.0 g/cm ³
Size(s) & Packaging	5 Litre jerry cans; 500 ml spray bottles
Coverage	1 litre will cover approximately 50 m ²
Storage	Store above 5°C in dry conditions in the original container.
Shelf Life	12 months
Active Ingredient(s)	Alkyl (C12 – 16) dimethylbenzyl ammonium chloride (0.2 % w/w)
Effective Against	Viruses, Bacteria

Application Information

NOPE!® Disinfectant Ready-For-Use is most effective when applied to a surface that has previously been cleaned.

NOPE!® Disinfectant Ready-For-Use can be applied by mopping, wiping or spraying. Apply the product to the surface and leave for a minimum of 5 minutes. This will give the disinfectant time to act. There is no need to rinse off the surface – it can be left to dry (except on food surfaces).



Food Contact Surfaces

NOPE!® Disinfectant Ready-For-Use can be used to disinfect food contact surfaces. However, it is important to ensure that the surface is disinfectant free before food comes into contact with it, by rinsing and wiping off after 5 minutes.

Test Data

Standard	Species	Result
EN 1276 (bactericidal activity – clean conditions)	Pseudomonas aeruginosa Staphylococcus aureus Enterococcus hirae Escherichia coli	Pass
EN 13697:2002 (bactericidal activity – clean conditions)	Pseudomonas aeruginosa Staphylococcus aureus Enterococcus hirae Escherichia coli	Pass
EN 13897:2015 (bactericidal activity – dirty conditions)	Listeria monocytogenes Salmonella typhimurium	Pass
EN 14476 (virucidal activity – clean conditions)	Poliovirus type 1 Adenovirus type 5 Murine norovirus	Pass

^[1] Based on testing to EN 1276, EN 13687:2002 and EN 13697:2015

^[2] Based on testing to EN 14476

Other Information

NOPE!® Disinfectant Ready-For-Use is unsuitable for use in fogging machines or on soft furnishings or fabrics.

Store in a safe place. Keep away from food, drink and animal feedstuffs. Keep out of reach of children and animals.

Use disinfectants safely. Always read the label and product information before use.

For full health and safety information consult Safety datasheet (available on request). Always read the label.

NOPE!® Disinfectant Ready-For-Use is produced in accordance with ISO 9001 and ISO 14001 quality and environmental management systems.

Information given is in good faith based on experience and usage, however all recommendations are made without warranty or guarantee, since the conditions of use are beyond our control. All goods are sold in accordance with our Conditions of Sale, copies of which are available on request. Customers are advised that products, techniques and codes of practice are under constant review and changes occur without notice; please ensure you have the latest updated information.